SKMEI
WATCH
1464

CATALOGUE

دیجی کوک

User Manual of SKMEI Mode #1464

RESET/SET (A key) ———————— (D key) DEC/-

———— (E key) ADJ

MODE (B key) ———————— (C key) START/STOP/+

A:Features

③ OLED display hour,minute, second,week, date, month, day,temperature function

③ 12/24 H Format selectable

③ Pedometer

③ 7-day step data query function

③ Compass

③ Alarm and Chime hourly

③ Stopwatch(maximum 23:59"59)

③ Count Down

③ Dual time

③ the LED will light on 10 seconds when press any key.

B:Synchronous needle function

In the Time mode, press E key to set the needle function, press and hold down E key to move the minute hand quickly.

C:Product mode loop

FRI 1·01 pm 02:11$_{33}$ — A key → — A key ← 1·0$_{10}$ 🌡29° pm 02:10$_{56}$

Time mode | Temperature-Time mode

D:Product function mode

FRI 1·01 pm 02:11$_{33}$ — B key → STU 00:00$_{00}$ — B key → TR 00:10$_{00}$ — B key → ALM AM 12:00$_{OFF}$

Time mode | Stopwatch mode | Countdown mode | Alarm mode

↑ B key ↓ B key

COMP N 2 ← B key — RECORD —— ← B key — 👣 STEP 0 ← B key — DT pm 02:14$_{44}$

Compass mode | Step record mode | Pedometer mode | Dual time mode

E:Product function settings

1. Time and date setting function

③ In the Time mode, press A key for 3 seconds to enter the time setting state. At this time,"12H"flashes, press B key "second" starts to flash,then press B key to select setting item (flashing) as following sequence:

| Time mode | 12H/24H | Second | Hour | Minute |

| Temperature calibration | Temperature unit | Day | Month | Year |

③ Press C key to increase the selected value, and press D key to decrease the selected value.

③ Press A key to confirm and return to the Time mode.

2.Stopwatch and segment timing function

③ The measurement range is 23 hours 59 minutes 59.99 seconds.

③ Set stopwatch: In the stopwatch mode, press C key to start running the second, then press C key to stop running, press A key to remove when the running seconds stop.

Process time

C key	C key	C key	C key	A key
Start	Stop	Restart	Stop	Remove

③ When the stopwatch is running, press B key to switch to other display modes,the stopwatch will continue to measure time.

3.Countdown function

③ The countdown timer can be set from 1 second to 24 hours. An alarm sounds when the countdown reaches zero.

③ Press C key to start/stop the countdown; when the countdown stops, press A key,the countdown time will automatically return to the initial setting time.

③ When the countdown reaches to zero, the alarm sounds for about 10 seconds or until you stop it by pressing any button. the countdown time is automatically reset to the initially setting time after the alarm stops.

③ Timing setting: In the countdown mode, hold down A key for 3 seconds until the ''hour''starts to flash, press B key to select setting item (flashing) as following sequence:

③ Press C key to increase the selected value, and press D key to decrease the selected value.

③ Press A key to confirm and return to the Countdown mode.

4.Alarm function

③ In the Alarm mode, press C key to switch the mode as follows:

Alarm mode   Chime hourly mode

③ In the relative mode, press A key to turn on/off the alarm and Chime Hourly function.

③ In the Alarm mode, hold down A key for 3 seconds until the ''hour''starts to flash, press B key to select setting item (flashing) as following：


③ Press C key to increase the selected value, and press D key to decrease the selected value.

③ Press A key to confirm and return to the Alarm mode.

Remarks：

③ In any mode, the alarm will sound for 10 seconds when it reaches the preset time. During the alarm, press any button can stop ringing.

③ The intermittent alarm sounds once every 5 minutes, sounds 7 times in total. You can press any key to interrupt the ringing.

③ After turned on Chime Hourly function,the watch will beep twice at each hour.


5.Dual time function

③ In the Dual time mode, hold down A key for 3 seconds until the ''hour''starts to flash, press B key to select flashing item.


③ Press C key to increase the selected value, and press D key to decrease the selected value.

③ Press A key to confirm and return to the Dual time mode.

6.Pedometer function

③ In Pedometer mode, press C key to "turn on/pause" the function.

③ In Pedometer mode,press A key to switch the mode as following.

Pedometer mode   Step mileage mode   Step calorie mode

③ In Pedometer mode,hold down A key for 3 seconds to start setting.

Pedometer mode   Set Metric/Inch   Set step distance   Set weight

③ Metric/Inch: The default is metric system, press C key to switch to metric or imperial.

③ Set weight: The default weight is 50kg (20IN), adjustable range: 20-200kg/44-440Lb;

③ Set step distance: the default step distance is 70cm (154LB), adjustable range: 30-200cm/12-79in;

③ Press C key to increase the selected value, and press D key to decrease the selected value.Metric/Imperial has no fast adjust function.

③ Press A key to confirm and return to the Pedometer mode.

7.Step record query function

③ In the Step record mode, press C key to query historical data within 7 days, and press A key to view the data for a certain day.


Step record query   Step query   Mileage query   Calorie query

8.Compass function

③ In Compass mode, turn the movement to display the compass angle.

③ hold down A key for 3 seconds into the Compass calibration mode.

Compass mode → Compass calibration mode 1 → Compass calibration mode 2

③ In Compass calibration mode 1,press C key when the arrow points to the 6 position , when OK appears then into Calibration mode 2.

③ In Compass calibration mode 2, hold the watch upside down ,press C key when the arrow points to the 12 position, when OK appears then the calibration is completed and back to the Compass mode.

③ Magnetic declination correction

Compass mode → Compass calibration mode 1 → Magnetic declination correction

③ Press C key to increase the selected value, and press D key to decrease the selected value.

③ Press A key to confirm and return to the Compass mode.