

CATALOGUE



SKMEI
DIGITAL WATCH
1134

كاتالوج



Operation instruction


A. Features

- ★ 12 Digits, Hour ,Minutes ,Seconds ,Month,Day and Week
- ★ Daily Alarm and Chime hourly
- ★ 12 / 24H,Auto Calendar
- ★ 1/100 second Chronograph with split count
- ★ EL backlight



B. Operational Manual


- ★ At any station , press A key , the EL back light on for 3 seconds.
- ★ Press B key to convert MODE:



Chronograph functions

In normal display mode: press B key once, enter Chronograph mode

- ★ Press D to start, press D again to suspend, press D again to continue, press D to suspend again,.....when suspend, press C key back to 0:00:00.
- ★ In Chronograph mode, press D key to start, press C key enter into split function, and the "SPL" symbol appear, press C key again to get the first group record ,but the second group still processing in the back ground, press C key again to continue the second group, press C key again to read the second group record.....when the final group finished, Press D key to stop the SPL function, press C key read the final group(SUM) record, press C key again to clear the record to zero.



Alarm & Chime ON/OFF

- ★ In normal mode, press B key twice to enter to Alarm Mode, Then press D to ON/OFF "ALM" /"SIG" function.
- ★ If "ALM/SIG" symbol appears , means ALM/SIG function ON, otherwise means OFF
- ★ "ALM/" appear means ALARM Function ON. "SIG/CHI/" appear means HOURLY CHIME function ON

Alarm setting

- ★ in normal Mode, press B twice to enter Alarm mode and press C then "Hours" flashing
- ★ Press D to adjust "Hour" for your Alarm. Pay attention to AM/PM
- ★ Press C then "Minutes" flashing, Press D to adjust "Minutes" for your alarm . Press B key to exit.

Time & date setting

In Normal Mode, press B three times enter into setting mode and the "Seconds" flashing, Press D to zero.

- ★ Press C the "Hours" will flash. Press D to adjust "Hours"
(Adjust the Hour circulatory, "H" appear means 24H format, "A/P" or "AM/PM" appear will be 12H format)
- ★ Press C the "Minutes" will flash. Press D to adjust "Minutes".
- ★ Press C the "Month" will flash. Press D to adjust "Month"
- ★ Press C the "Date" will flash. Press D to adjust "date"
- ★ Press C the "Week" will flash. Press D to adjust "Day"
- ★ Press B key to exit.