



# SKMEI DIGITAL WATCH 1025



# Operation Manual



## Functions

In normal display mode shows: month -date-week- hour -minute - second

Modes change: press S3 button

Back light press S4 button

## Modes of watch

Normal display modes press S3 → chronograph mode → alarm setting mode → time setting mode

## Chronograph functions

In normal display mode: press S3 once → enter chronograph mode → press S1 to start → press S1 to stop → tap S3 to exit  
press S1 to stop ← press S2 to read time ↔ press S2 to SPLIT → press S2 to reset  
press S1 to stop ← press S2 to read time ↔ press S2 to SPLIT → press S2 to reset

## Set up to alarms

**Hours:** In normal display Mode, press S3 twice to the alarm mode ,then press S2 the “Hours” flashing , press S1 to adjust the Hour.

**Minutes:** Press S2 again the “Minutes” flashing, press S1 to adjust the Minutes.

**Tap S3 to save / exit.**

## Alarm and chime ON/OFF

In normal display Mode, press S3 twice to the alarm modes,press S1 to ON/OFF alarm function,if the symbol of “ALM” appear , means alarm ON, otherwise means OFF. same action to ON/OFF hourly time signal function, if the “SIG” appears to ON this function, and the watch will chime hourly , otherwise will not.

## Set time & date

In normal display Mode, press S3 three times to enter Time&Date setting mode and "the seconds" flashing.

**Hours:** press S2 and the hours will flash, press S1 to adjust the hours (“H” means 24H format)

**Minutes:** press S2 and the minutes will flash, press S1 to adjust the minutes.

**Months:** press S2 and the month will flash. press S1 to adjust the month (1=January, 2=February ...)

**Date:** press S2 and the date will flash. press S1 to adjust date

**Day of Week:** press S2 and the day of the week will flash. press S1 to adjust the week (MO=Monday...)

**Tap S3 to exit.**